

IN-LINE INSPECTION OF HOT-ROLLED STEEL PRODUCTS BY HEAT FLUX THERMOGRAPHY

Stefan Koch, Institut Dr. Foerster GmbH & Co.KG



**FOP Spring Conference 2015
Gothenburg**





AGENDA

- Typical defects on hot-rolled steel surfaces
- Non-destructive testing by magnetic particle inspection (MPI)
- Principle and inspection setup for inductive thermography
- Inspection steps
- Heat flux thermography
- Conclusion



CRACKS






FOERSTER
proof.





CRACKS: MICROGRAPHS

FOERSTER
proof.





SHELLS



FOERSTER
proof.





MAGNETIC PARTICLE INSPECTION

FOERSTER
proof.





MAGNETIC PARTICLE INSPECTION: LIMITATIONS


Degree of automation

- Test results depend on the individual operator
 - Limitation of inspection speed
 - Depth identification and discrimination is not possible
→ High false indication rates
 - Lack of detailed documentation
 - No Level 2 integration possible
-
- Working environment
 - Large space requirements
 - Difficult working conditions regarding UV-lighting and chemical handling
 - Used solvents affect the environmental safety
 - Additional working steps (demagnetizing, cleaning)



PRINCIPLE: INDUCTIVE THERMOGRAPHY


FOERSTER
proof.





TEST EQUIPMENT

FOERSTER
proof.





STEP 1: WETTING


FOERSTER
proof.






EMISSIVITY OF STEEL WITH A THIN WATER FILM

FOERSTER
proof.



Without water:

Local variation of
emissivity



With water:


Homogenous
emissivity

$$\varepsilon \approx 0.95$$






STEP 2: HEATING

FOERSTER
proof.






TEMPERATURE INCREASE IN PRESENCE OF A FLAW





STEP 3: IMAGE AQUISION


FOERSTER
proof.





THERMAL IMAGE


FOERSTER
proof.





THERMAL IMAGE


FOERSTER
proof.





THERMAL IMAGE


FOERSTER
proof.





STEP 4: IMAGE PROCESSING

FOERSTER
proof.






HEAT DISSIPATION IN CRACK


FOERSTER
proof.

Progression of defect profile

Thermal image






Temperature profile of defect





NEW CONCEPT: HEAT FLUX THERMOGRAPHY

FOERSTER
proof.




- Up to 30 shots of every single position in the ‚Field of View‘ !
- 100 frames/s, 640x512px, MWIR
- Resolution 1/2 mm x 1/2 mm




TIME-DEPENDENCY OF DEFECT PROFILE

FOERSTER
proof.

Image sequence of moving billet




Temperature profile of defect






TIME-DEPENDENCY OF DEFECT PROFILE PARAMETERS

FOERSTER
proof.



Defect profile
at different times





Time dependency

- defect amplitude
- heat concentration



BEHAVIOUR OF NOISE (CASE 1)



FOERSTER
proof.



Broad amplitude,
therefore small concentration
and concentration change rate



BEHAVIOUR OF NOISE (CASE 2)




Increase of signal amplitude,
also increase of concentration



CRITERIA FOR DEFECT RATING

- Amplitude ΔT of defect signal \rightarrow main criterion that defines the depth of the defect



- Cooling rate of defect signal in longitudinal direction
- Change rate of heat concentration in defect
- Shape of the 'crack' signal



CONCLUSION

Thermography

- Contactless
- Max. inspection speed: 1.5m/s
- Complete inspection of test piece with minimum untested end

Usage of Focal plane array (FPA)

- Detection of very short defects → Minimum defect length: 10mm

Heat Flux Thermography

- Excellent suppression of false indications → minimum repair costs
- Improvement of signal-to-noise ratio → minimum defect depth: 0.3mm



FURTHER CAPABILITIES

FOERSTER
proof.

- Full documentation of request, piece and defect results as well as all testing conditions and parameters
- Automatic marking and sorting
- Level 2 integration



IMPRESSIONS IN FINISHING LINE

FOERSTER
proof.



DEFECTOVISION® IR



Contact:

Stefan Koch

Institut Dr. Foerster GmbH & Co.KG

In Laisen 70

72766 Reutlingen

Germany

Email: koch.stefan@foerstergroup.de

proof.